

# Instructions: Frame without Mat

Watch the video online!

Scan the QR code:



Or go to:

[www.framingonline.co.nz/Tutorials](http://www.framingonline.co.nz/Tutorials)

1. Ready to assemble.



2. Place the frame face-down & bend the tabs back.



3. Remove the backing board and leave glass in the frame.



4. Insert your item into the frame face-down against the glass & place the backing board on top.



5. Bend the tabs back down.



6. Ready for cord.



*Turn page over for tying cord...*